


HOW TO CLEAN



SUITABLE FOR 710 SERIES

Coil is consumable, so please replace it after using for a while.



ORIGINAL DESIGN BY LOOKAH
MADE IN CHINA
www.lookah.com



LOOKAH®
ORIGINAL DESIGN ONLY

USER MANUAL V1.0

PRODUCT OVERVIEW



PRODUCT FEATURES

1. Replaceable and multiple choices of atomizing core
2. The built-in display screen shows the voltage mode and battery charge.
3. Three-mode voltage adjustment to meet different needs
4. Magnetic flip cap that is easy to use
5. Capacity of battery: 950mAh
6. Charging current: 380mA
7. Charging input voltage: USB 5V

HOW TO USE

1. Open the magnetic flip-cap and put the wax into the atomizing coil.
2. Press the power button 5 times within 2 seconds to turn on the device. The battery LED flashes 3 times and then the device starts automatic preheating and displays a countdown like "9, 8, 7---0" on the screen. The preheating lasts 10 seconds, which can be stopped by pressing the button once.
After the preheating is done, the battery light will flash 2 times, and the device enters the current voltage setting.

CHANGE VOLTAGE

1. Press the power button 2 times within 0.8 second to change the voltage:
Mode 1 > Mode 2 > Mode 3 > Mode 1.
Mode 1: 3.2V Mode 2: 3.6V Mode 3: 4.0V

MANUAL MODE

1. Press and hold the button to start vaping, (Continue to hold the power button for up to 30s). After 30s the device will stop heating, the indicator light will flash 5 times and the device will enter standby.
2. Turn off: Press the button 5 times within 2s to turn off the device. (The indicator light will flash 3 times.)
3. The device will automatically turn off if there is no operation for 60 minutes.

Caution: It can damage the atomizer coil or the device if it is used without wax in the atomizer coil.

ALARMS IN CASE OF ABNORMALITY

1. Low battery alarm: "L" is displayed. Please charge the device before use.
 2. Short-circuit alarm: "0" is displayed. Please replace the atomizing coil before use.
 3. Open-circuit alarm: "9" is displayed. Please replace the atomizing coil before use.
- Timeout protection Overcharging protection
Short-circuit protection Low battery protection

CHARGING STATUS OF LED LAMP

1. When Charging: The battery LED indicator bars will flash counterclockwise in scrolling form.
2. When the battery is fully charged: The battery LED will remain on with all bars lit while the USB cable is connected.

NOTES

1. This device is a high-temperature product, it is normal that the housing becomes moderately heated during use.
2. If the housing gets too hot to touch by hand during use, please stop using the device, turn it off and allow it to cool down.

KIND REMINDER

For better understanding and use of this device, please carefully read this manual prior to the first use.

1. This product is not intended for use by persons under legal smoking age, nonsmokers, women who are pregnant or breastfeeding, or persons with or at risk of heart disease, high blood pressure, diabetes, or persons taking medicine for depression or asthma
2. Battery built-in the device. Please do not expose the device to high temperature, cold or humid environments.
3. Do not expose the device to water.
4. Turn off the device when not in use.

WARRANTY

30 days from the date of purchase against manufacture defects. Does not apply to improper use. Used consumables are not covered by the warranty.