



On/Off:

- Press and hold the button for 2 seconds to turn on or off
- Ghost² has a 15 minute auto shut-off feature

Change Temperature Setting

- Click button once to view the current temp setting
- Click again within 3 seconds to change the temp setting
- LEDs will pulse the new temp setting color (Purple, Blue, Cyan, Yellow, White)

Heating

- Click button x2
- LED Illuminates **Red** when heating, and changes to **Green** when reaches set temperature
Hold Time = 30 seconds

Cancel Heating

- Click button (During Heating Cycle)
Heating cycle will immediately cancel

Setting	Default Temperature (°F)	LED
Setting 1	420	Purple
Setting 2	450	Blue
Setting 3	480	Cyan
Setting 4	510	Yellow
Setting 5	540	White

= The Default and Our Recommended Setting

Heating Mode

- Click button x3
Unit will cycle between the different heating modes
- LEDs will illuminate in a pattern representing the heating mode

Downward = Descent, Pulse = Steady, Upward = Ascent

Battery Status

- Click button x4
LED will light up to indicate the battery percentage:

Green > 70% - **Yellow** 30% to 70% - **Red** < 30%

Auto Shut-Off

- LED will illuminate in the downward pattern to indicate powering OFF, but will not vibrate

Auto shut-off occurs if unit is left idle for 15 minutes

Low Battery

- LEDs flash White x3 when user attempts heating. Occurs when battery is <30%, or at **Red**
- If battery is too low to run a heating cycle, LEDs will flash White x3 then power off

Charging

- LEDs will swipe upward White during charging, and stay Solid White when fully charged

Unit has passthrough charging and can charge while operating

Manual Calibration

- While OFF: Click button x4 and Hold for 8 sec
- Calibrate the device when changing eChamber
Only should be done at **room temperature**
- Success = LED will flash **Green** x3
Failure = LED will flash **Red** x3

Support

Warranty

Dr.Dabber offers a 1 year warranty on the Ghost² battery, charging cable, and electrical components. Accessories, eChambers, mouthpiece, damage caused by improper use of the unit, and cosmetic issues are not covered under warranty.

If you have any issues with our products, please contact our Customer Service Department by emailing info@drdabber.com.

All 3rd party purchases will be required to provide proof of purchase.

Registration

Register your Dr.Dabber product today to receive helpful tips, faster technical support, and to activate warranty.

drdabber.com/register

Safety

Our products are intended for use by persons of legal age. Not by children, women who are pregnant or breastfeeding, or persons with or at risk of heart disease, high blood pressure, hypertension, diabetes, or taking medicine for depression or asthma. Discontinue use and consult a physician if you experience symptoms such as nausea, vomiting, dizziness, diarrhea, weakness, rapid heart-beat, or hypertension.



WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov



DESIGNED IN THE USA. MADE IN CHINA.

