

Caution:

Keep the device away from any environment involving strong acids, alkaline, combustible materials, water, or any other liquids.

Do not keep in hot cars or store above the room temperature of 74°F.

Do not use damaged batteries. If the battery casing is damaged, discontinue use and safely recycle the battery.

Do not use the battery if contacts become exposed to solid or liquid matter.

Shorts can result in fire or an explosion of a battery.

Do not touch coils when hot. Severe burns can result.

Do not touch hot material. Severe burns can result.

If the device gets too hot in use, please stop using it for a while.

Not intended for tobacco or nicotine use.

Not an ENDS device.

Disclaimers:

People under 21 years of age are not permitted to purchase or use this device. Non-smokers, children, and women breastfeeding should not use this product.

The device is not a medical device and is not intended to diagnose, cure or prevent any diseases or other conditions. The manufacturers and sellers will not be responsible for any consequential or incidental damage resulting from the sale or use of any merchandise.

YoCan®



Nestor

Instruction Manual

Specification:

Size: 27.5*27.5*104.2mm

Coil Resistance: 0.8Ω

Battery Capacity: 900mAh

Voltage Range: 2.5-4.2V

Safety Cut-off: 15 Seconds

Charging Type: 5V/1A Type-C

Charging Time: 1.5h


Package Content:

1x Nestor Device


1x Pick Tool

1x Instruction Manual

1x Type-C Charging Cable



How To Use:



1. Turn on/off: quickly click the power button 5 times within 2 seconds.
2. Pull out the magnetic mouthpiece, fill the concentrate into the QTZ I coil and then put the magnetic mouthpiece back on.
3. Adjust the voltage: click +/-.
4. Working: on-demand mode & auto-mode.
- 4.1). On-demand mode: press and hold the power button.
- 4.2). Auto-mode: 2 times click enter into auto-mode, 15 seconds safety cut-off.

The output voltage will be your settled voltage, voltage adjustment is not supported during the session.

5. Charging: Type-C port. fast charging not supported. charging time around 1.5 hour, battery indicator goes off once fully charged.

Protection:

1. Auto shutdown after 30mins.
2. Safety cut-off: 15s safety cut off.
3. No load: 2.5 quickly flash 3 times if the device haven't connected coil.
4. Short-circuit: 2.5 quickly flash 5 times if the device is shorted.
5. Low battery: battery indicator color turns to red, quickly flash 10 times and stops working.
6. Over charge protection.